

Midi Maestro BB Mode Command set, as report by Midi Monitor

Screen #1

<i>Start/Stop</i>	<i>Scroll Up</i>	<i>Enter/Exit Folder</i>
CC 114, 1 (start)	CC 119, 1	CC 118,1
CC 115, 1 (stop)		

<i>Accents Hits></i>	<i>Scroll Down</i>	<i>Tap Tempo</i>
Goes to Screen #2	CC 119, 0	CC 117,1

Screen #2

<i>Exit></i>	<i>Clap</i>	<i>Tambourine</i>
Goes to Screen #3	D#1 Note on	F#2 Note on

<i>Hi Hat Closed</i>	<i>Snare</i>	<i>Kick</i>
F#1 note on	D1 Note On	C1 Note on

Screen #3

<i>Stop</i>	<i>Previous Part</i>	<i>Next Part</i>
CC 115,1	CC 113,126	CC 113,127
Goes to Screen #1	CC 113, 0	CC 113, 0

<i>Accent Hits</i>	<i>Select Part</i>	<i>Tempo</i>
Goes to Screen #2	Goes to Screen #4	Goes to Screen #5

Screen #4

<i>Exit</i>	<i>Part 1</i>	<i>Part 2</i>
Goes to Screen #3	CC 113, 1	CC 113, 2
	CC 113, 0	CC 113, 0

<i>Part 3</i>	<i>Part 4</i>	<i>Part 5</i>
CC 113, 3	CC 113, 4	CC 113, 5
CC 113, 0	CC 113, 0	CC 113, 0

Screen #5

<i>Exit</i>	<i>Double Time</i>	<i>Tempo Up 1 BPM</i>
Goes to Screen 3	GP 8, 1	GP 5, 1
	GP 8, 0	

<i>Tap Tempo</i>	<i>Half Time</i>	<i>Tempo Down</i>
CC 117, 1	GP 7, 1	GP 6, 1
	GP 7, 0	

Expression Pedal Input:

Toe Down to all the way Up
GP 6, 5
GP 6, 66
GP 6, 56

Toe Up to all the way down
GP 5, 4
GP 5, 71
GP 5, 52

Note: Midi Monitor is showing what I labeled as GP as, "General Purpose"